



JEEP JL RUBICON HIGH-LINE FENDER BRACKETS

INSTALLATION INSTRUCTIONS

STEP 1 - WATCH THE VIDEO

Near the bottom of the product page on our website, there is a very detailed instructional video. You can see that video at <https://americanadventurelab.com/highline>.

STEP 2 - OPTIONAL FENDER BOLT

For the longest time, I resisted the urge to bolt the fender down to the bracket. Personally, I have put thousands of miles on my JL with the fenders "resting" on these brackets. However, due to customer requests, I have now included a tab on the outside of the bracket, to which you can bolt the fender. This bolt will definitely be helpful in side draft windy situations.

There is enough room on the inside of the fender to get most small drills lined up perfectly. While holding slight pressure downward on the top side of the fender, you can drill from the inside of the fender outward through the hole in the outside tab. To do this, use a 1/4" drill bit.

Once the hole is drilled, use the supplied 6mm bolts and nuts to secure the fender down to the bracket.



NOTE:

Use supplied Dielectric Grease on all electrical connectors when installing the lights. To prevent corrosion to connections.

