



2007-2014 JEEP JK HANDLE INSERTS

INSTALLATION INSTRUCTIONS

PART NO: JP-190015



Thank you for purchasing a quality Drake Off Road product. Please refer to the installation instructions below when installing this product.

SHOWN: JP-190014

TOOLS REQUIRED:

- Drill motor #52 (.0635") drill bit
- T10Torx Driver
- Center punch or something to mark a hole location with (long tipped Sharpie)

INSTALLATION:

Remove stock handle:

1. Line up Drake Jeep Door Handle Insert so that it sits flush and follows the door handle lines.
2. While holding it in location, use center punch or other marking device to mark drill location of two mounting holes.
3. Remove Door Handle Insert and drill two marked locations using a #52 Drill Bit. Take extreme caution to not go too deep and drill into sheet metal portion of door.
4. Position Door Handle Insert and secure using 2 included screws. Tighten until snug using T10 Torx driver.

INSTALLING THE MESH



Step 1



Step 2



Step 3



SATISFACTION GUARANTEE:

If you are not happy with this product, for any reason, or found product to be defective in manufacturing, simply return it to Drake Off Road within 30 days of purchase and we will replace it - no questions asked. We stand behind our products one hundred percent, so you can sit behind the wheel with pride.

**Proof of purchase and dated receipt must be present with any return. All returned products are tested and if found to be damaged by the installer, no replacement will be issued. You pay the the cost to ship to us, we pay for the return shipping. Guarantee does not include any labor and/or tax charges incurred.*

IS-DOR- JP-190015