



# PART # 6034

2018 AND UP  
Installation Instructions JL JEEP WRANGLER

If your AMI STYLING product has a damaged or missing part, or for warranty issues, please contact customer service directly and a new replacement part will be sent to you immediately.

## Bill Of Materials

- 1-Billet Fuel Door
- 1-square driver bit
- 6-Square-Drive Flat Head Screws

## Tool Needed For Installation

- Hand Drill
- 9/64 Drill bit
- 1/4 Hex driver

**(877 759-9991)**

MON-FRI 7AM-4PM PST

OR

**EMAIL:** [support@readylift-ami.com](mailto:support@readylift-ami.com)

**WEBSITE:** [amistyling.com](http://amistyling.com)

## Limited Lifetime Warranty

This unique product warranty proves our commitment to the quality and reliability of every product that AMI STYLING manufactures. The AMI STYLING product warranty only extends to the original purchaser of any AMI STYLING product. If it breaks, we will give you a new part. Warranty does not apply to discontinued parts.

Our Limited Lifetime Warranty excludes the following AMI STYLING items; bushings, chrome, and powder coat. These parts are subject to wear and are not considered defective when worn. They are warranted for 3 months from the date of purchase for defects in workmanship.

Product purchased directly from AMI STYLING has a 90 day return policy on uninstalled products from the date of purchase (may be subject to restocking fee). Uninstalled product returns must be in the original AMI STYLING packaging. Please call **(877) 759-9991** to get an RGA# for any return. Customer is responsible for shipping costs back to ReadyLIFT. **Returns without RGA# will be refused.** Contact ReadyLIFT directly about any potentially defective parts prior to removal from vehicle.



**FAILURE TO PERFORM THE POST INSPECTION CHECKS MAY RESULT IN VEHICLE COMPONENT DAMAGE AND/OR PERSONAL INJURY OR DEATH TO THE DRIVER AND/OR OTHERS.**

**This product is designed for static use only, The Vehicle must be in the park position with the parking brake applied, And the engine in the off position. Do not use this product when the vehicle is or could be in motion. Do not use this product when the engine is starting, or running. The misuse of this product could case injury or death to the driver and/or others.**

### Final Checks & Adjustments

RECHECK ALL HARDWARE FOR PROPER TORQUE VALUES AFTER 500 MILES, AND THEN PERIODICALLY AT EACH SERVICE INTERVAL THERAFTER.



# PART # 6034

2018 AND UP

Installation Instructions

JL JEEP WRANGLER

**The drilled holes will only go through plastic  
They WILL NOT go into the steel body.**



1. Place your new billet aluminum fuel door over the fuel shroud. Make sure the hinge side of the door is facing towards the front of the Jeep and the finger pull is parallel with the body line. Make sure to avoid contacting the metal body.
2. With a 9/64 drill bit, drill the first hole in the 12 o'clock position and install a square-drive flat head screw to hold the door in place.
3. Make sure the door is still seated on the fuel shroud and drill the 5 remaining holes. Install remaining 5 square-drive flat head screw, and tighten the screws evenly so you don't distort the plastic.

