



GAUGE POD®

JEEP TJ A Pillar Mount
Gauge pod
PART NO 17502
FITS ALL JEEP TJ FROM
1997-2002

KIT INCLUDES

- 1ea. GAUGE POD
 - 1ea. Phillips head screw
 - 1ea. Alcohol swab
- Make sure kit is complete before Beginning installation

REQUIRED TOOLS

- 1ea. Phillips head screw driver

PRIOR TO INSTALLATION

- ▲ The ambient air temperature (the temperature of the vehicle, and Trailready gauge pod) must be between 60° - 110° F. This is critical in order for the 3M® brand VHB tape to properly adhere per the manufacturers specifications. Failure to follow these guidelines will result in poor adhesion and possible panel loosening.
- 1. Dry fit the gauge pod as you proceed with the installation. Note the tape line position. These areas must be cleaned with a degreaser such as rubbing alcohol to ensure proper adhesion.
- 2. If you plan on painting your Trailready® Gauge Pod it must be done prior to installation. All surfaces must be cleaned using a scuff type sanding paste and prepped using an adhesion promoter. Follow all specifications required by the paint manufacturer

INSTALLATION INSTRUCTIONS

1. Fit and install your gauges into the gauge pod following the instructions included with the gauges you purchased. This must be done BEFORE you begin the Gauge Pod installation process.
Note: This pod only accommodates 2" to 2 1/16" gauges. Any attempt to install other than these size gauges will void your warranty.
2. Locate and remove the middle screw on the drivers side A pillar plastic door seal stop.
3. Pre fit the gauge pod aligning the hole in the pod with the hole in the pillar door seal. Note the tape line position. Note the position of the pod relative to the windshield rubber seal.(you may need to view the pod from the outside of the vehicle to note any unsightly gaps. Once you are familiar with how the pod should look once installed proceed to the next step.
4. Clean the tape line area with the supplied alcohol swab (All tape areas must be cleaned as described ▲ above)
5. Peel red vinyl backing from tape.
6. Position the back area of the gauge pod over the rubber seal on the Windshield and twist the pod until the pods lip (the lip that has double sided tape) is over the plastic door seal. Using the screw hole as a guide, align the hole in the pod with the hole in the plastic door seal stop.
7. Take care not to exert pressure on the adhesive tape before you have aligned the pod properly. Once you have checked for proper location apply firm pressure to the areas of the parts opposite tape pads to ensure proper tape adhesion. (See ▲ above)
8. Finish the installation by installing the Phillips head screw included in the kit. DO NOT over-tighten.

The name's and logo's TAG The Accessory Group, Trailready, Bogyguard and Proguard are © & ® by TAG The Accessory Group Inc. All rights reserved. This product is warranted to be free from defects in material and workmanship for 90 days from original purchase date if properly installed, and subject to normal use. Improper installation procedures, alterations, misuse and abuse of this product will void all stated warranty provisions. Products returned and deemed to be covered by warranty will either be replaced with said merchandise or issued credit for same.

TAG The Accessory Group Inc. 1025 Segovia circle Placentia Ca. 92870 714-630-6875