



# INSTALLATION INSTRUCTIONS

**PART No.** FB24086 & FB24087

**Jeep® JL Wrangler  
Tube Doors – 4DR and 2DR**



**FB24086 – 4DR (SHOWN)  
FB24087 – 2DR (FRONTS ONLY)**

## REQUIRED TOOLS

13mm Socket/wrench  
4mm Allen wrench

## KIT CONTAINS

Stainless nyloc nut (2DR)  
Stainless nyloc nut (4DR)

## QTY

4  
8

### 1) REMOVE DOORS

Begin by removing your OEM or existing doors. Take care not to scratch the doors when removing and place them on a soft surface to protect the paint.

### 2) INSTALL TUBE DOORS

Insert the tube doors into the Jeep's body hinges and secure with supplied nyloc nuts using a 13mm wrench or socket. Do not overtighten as this may make the door hard to open.



2408600

## INSTALLATION INSTRUCTIONS

**PART No.** FB24086 & FB24087

**Jeep® JL Wrangler  
Tube Doors – 4DR and 2DR**

**3) ATTACH DOOR CATCH STRAP**

Install the attached door catch strap to the hook inside the Jeep.



**5) ENJOY YOUR FISHBONE OFFROAD TUBE DOORS!**



**4) ADJUST LATCH MECHANISM**

Using a 4mm allen wrench, adjust the latch mechanism until the door closes smoothly.

